Puroma 4-Digit Combination Key Storage Lock Box

▪ To open the key box:

1. Slide the shutter board, scroll dials to the combination you set. The Factory Default Code is 0-0-0-0.
2. Push down the black button near the dials to open the box.
3. After the box door is open, keys can be put in or taken away.
4. After closing the door, mess up the dials to protect your combination and close the shutter board.

▪ To set your combination:

1. Open the key box, keep dials at the correct combination. (Factory default combination is 0-0-0-0)
2. Push the RESET button from position A to position B, as shown in Pic.1.
3. Now scroll dials to set your own combination.
4. Push the RESET button back to position A. Now the new combination has been set. Take a photo to save your password.



Pic.1

▪ IMPORTANT NOTES

- Keep the shutter board closed for water resistance.
- Always look straight on the numbers of the dials, otherwise you may misalign them with the reference line, which could cause the password actually set is different from what you want.



- If you cannot open the lock by the default code "0000" on first use, please try with the code "1000", "0001", "9000" or "0009" to open again.
- It is recommended that the dials are scrolled weekly to keep them work well.

▪ Package Content

1 x Combination Lockbox
4 x Screws
4 x Plastic Expanded Plugs
2 x Black Rubber Plugs
1 x User Manual

▪ Method 1: Lock on the door handle

▪ Method 2: Mount on the wall

1. Open the box, pull the button inside the box from right side to left to plug out/in the shackle.



2. Insert black rubber plugs into the 2 small holes at the top of box to prevent dust and water from entering the box.



3. There are 5 holes in the back of the box, hold the box to the wall and mark position of holes with a pencil.
4. Using impact drill the holes into wall. The diameter of every small hole is 6mm.
5. Knock the plastic expanded plugs into the hole.
6. Place the box against wall with screws.



▪ After-sale service

Our product is guaranteed for **12** months from the day of purchase, please contact us if needed:

- Refund or Replacement
- Technical Support
- Package Not in Perfect Condition

support@puroma.net

Scan QR code or enter the link to visit Puroma official website for more help.

Link: www.puroma.net